



40 Terra Cotta Drive
Blackburn Vic 3130
Allan Cook 0438 312 997
ABN: 74608039185

INSTALLATION OF ENGINEERED OAK FLOORING TO HEATED SUBFLOOR GUIDE

ASP Oak flooring due to its great stability, is an ideal product to go over heated slabs and substrates, but does need to be installed as per the guidelines specified to avoid compromising your flooring warranty.

Please also note that the heating system being used must be installed and operated in compliance with the guidelines of the heating and/or other manufacturers guidelines.

ASP Oak Flooring can be installed over a heated slab using both installation methods – direct stick or floated.

Please refer to our installation instructions or contact us for more information.

The in-slab under floor heating needs to be started and run at desired temperature for at least 2 weeks prior to installation of ASP Oak Flooring.

NOTE: The slab surface temperature must not exceed 25 degrees Celsius at all times.

After 14 days, turn off slab heating and allow 4 days to pass in order to allow subfloor to cool down and reach room temperature before installation.

Please note that the total timber floorboard thickness is to be no greater than 20mm.

After floor installation is complete, your ASP Oak flooring requires gradual climatization in conjunction with the heating system.

Heating system temperature is to be increased by **2 degrees** increments each day until desired temperature is reached (not exceeding 25 degrees Celsius) and when turning your heating off, also **decrease by 2 degrees** increments each day until it is off.

Shrinking between boards, cracking and minor cupping can be expected when installing over radiated floor heating and does not constitute as a product defect.

For Trowel Glue / Direct Stick Method:

Please refer to our ASP oak Flooring Installation Instruction Guide for Trowel Glue/ Direct Stick Method.

Glue adhesive must be applied to subfloor using method of trowelling. Make sure to consult the glue adhesive manufacturer to ensure the appropriate adhesive is used in conjunction with a heated slab installation.

Disclaimer: ASP Timber Floor has used its reasonable endeavours to ensure the accuracy and reliability of the information contained herein and, to the extent permitted by law, will not be liable for any inaccuracies, omissions, or errors in this information nor for any actions taken in reliance on this information. Products must be installed in accordance with relevant installation recommendations and industry best practices.

Any further questions or requirements please feel free to contact the following

Allan Cook
Sales Manager
0438 312 997
allan@asptimberfloor.com.au

Kevin Xu
General Manager
0413 252 024
sales@asptimberfloor.com.au